



Indra500 compatibility with Odin II Pentax

The Odin II Pentax has featured new functionality in which a firmware (version S.W V3.00) update is required with existing Indra500. This guide will help to highlight the changes.

Firmware update

- 1) Connect the Indra500 to the computer via USB cable
- 2) Run the firmware updater
- 3) Load the firmware (.FDS file) and icon(.FIF file) via the software and icon option
- 4) Disconnect the Indra500

Note: Firmware S.W V3.00 is NOT compatible with current Odin II Canon and Nikon transmitter

Changes

- 1) Under RX setting, Odin-C, Odin-N, Odin-S, Strato II becomes Odin II and Ares II respectively (For Strato II please use the Ares II setting, and for Odin II Pentax please use the Odin II setting)
- 2) Channel 1-4 now supports group D and E as well as digital ID (Odin II Pentax transmitter and Ares II support)
- 3) The Menu page has been reduced to 3 pages (Menu 4 will be removed)
- 4) The following feature will be moved to C.Fn (custom function) in Menu 3: Buzzer, quick flash, display color and auto rotate
- 5) When using Odin II Pentax, the Indra500 display will reflect the power setting on the Odin II Pentax transmitter in real time.