


mini A

Single-pin mini
manual flash with LED

Instruction Manual



Features

The Phottix Mini A Flash is a compact on camera flash with LED light source for still and video photography. It uses the latest in flicker-free LED technology.


The Phottix Mini A Flash features:

- Single pin hot shoe manual flash
- Built-in recharge battery
- LED warm / cool color selectable
- Flash manual power control
- Front-fill LED power control
- Front-fill light LED CRI 95+
- Recharge input: 5V USB-C
- Flash head rotates 90 degrees

Please note:

- Do not shine directly at people's eyes at short distances.
- Do not place close to alcohol or flammable objects.
- Do not place liquids on or near.
- The product is not water, splash or dust resistant.
- Do not use strong cleaning agents or solvents such as thinner gasoline or alcohol to clean.
- Do not store at temperatures of +40C as high temperatures may damage the product components.
- Do not use in outdoors in direct sunlight for an extended period of time to prevent the product from overheating and possible damage.
- Because of the built-in Lithium-Ion Battery - do not disassemble, crush or incinerate.
- Please use the specified charger within the specified voltage and temperature range.
- To keep the battery in proper working order use the product and charge the battery at least once per month.
- If left unused for a long period of time recharge before using.
- Lithium-ion battery cells lose capacity over a product's lifetime. Performance will be reduced.

Parts



Turning Power On/Off

- Press and hold the Power button for 1 second to turn the unit on or off.

Mode Selection

- Press the Mode button to cycle through Flash, LED, and Flash + LED modes

Flash Mode

1. Press the Level button to select flash output power: 1/8, 1/4, 1/2, or 1/1.
2. A green light indicates the flash is ready.
3. Press the Flash button to test the flash.

LED Mode

1. Press the Level button to select the LED output level.
2. Press the CCT button to select a color temperature: 2500K, 3200K, 4500K, or 6200K.

Flash + LED Mode

1. Press the Level button to select flash output power: 1/8, 1/4, 1/2, or 1/1.
2. A green light indicates the flash is ready.
3. Press the Flash button to test the flash.
4. The LED color temperature is preset to 6200K.
5. LED output level selection is not available.

Mounting on a Camera

1. Turn off the unit.
2. Slide the unit onto the camera's hot shoe.
3. Turn on the unit.

Charging the Phottix Mini A Flash

The Phottix Mini A Flash charges via a 5V USB-C input.

1. Connect the appropriate USB-C cable to the Phottix Mini A Flash.
2. Attach the cable to a USB power source.
3. The Charging LED will turn green when charging is complete.

Tech Specs

Battery:	3.7V 300mAh (1.11Wh)
Flash power:	GN8
Flash color temperature:	6500K
Flash recycle time:	4sec @ 1/1 power output
Flash battery cycles:	about 480 times @ 1/1 power output
LED battery life:	about 1hr
Color rendering index:	>95
LED numbers:	12pcs 120deg LED
LED Max. Brightness:	200Lux @ 0.3m 6200K
LED color temperature:	2500K / 3200K / 4500K / 6200K (+/-200K)
Battery recharge time:	about 1hr (5V 1A)


What's included:

- Mini A Flash
- USB-C recharge cable
- Hand strap

mini A

單點迷你手動閃光燈
(內建LED補光燈)

使用說明書



產品特色

Phottix Mini A 閃光燈是一款輕巧的機頂閃光燈，配備 LED 光源，適用於靜態攝影及影片拍攝。採用了最新的無頻閃 LED 技術。


Phottix Mini A 閃光燈的特點包括：

- 單按點熱靴手動閃光
- 內建可充電電池
- LED燈可選暖色 / 冷色
- 手動閃光功率調整
- 前方補光LED功率調整
- 高顯色性 CRI > 95 的前方補光燈
- 充電輸入：USB-C，5V
- 閃光燈頭可旋轉 90°

注意事項

- 請勿在短距離直射人眼
- 遠離酒精及易燃物品
- 不要在設備上或周圍放置液體
- 本產品不具防水、防塵或防濕功能
- 請勿使用強力清潔劑如稀釋劑、汽油、酒精清潔
- 請勿存放於高於攝氏 +40 度環境
- 避免長時間曝曬於太陽下，避免過熱損壞
- 因內建鋰電池，請勿拆解、壓碎或焚燒
- 請使用指定充電器並在規定的電壓及溫度範圍內使用
- 建議每月使用並充電一次以維持電池性能
- 長期未使用時，請先充電再開機
- 鋰電池性能會隨使用時間下降

部件說明



1. 閃光燈頭
2. LED 面板
3. 熱靴接座
4. 功率顯示
5. 閃光 / 色溫切換鍵
6. 電源 / 模式切換鍵
7. 功率調整鍵
8. 充電指示燈
9. USB-C 插口

開關電源

- 長按電源鍵 1 秒開 / 關機

模式選擇

- 按模式鍵切換：閃光 / LED / 閃光+LED

閃光模式

1. 按功率鍵調整：1/8、1/4、1/2、1/1
2. 綠燈亮時可閃光
3. 按閃光鍵測試閃光

LED模式

1. 按功率鍵調整 LED 亮度
2. 按色溫鍵選擇：2500K / 3200K / 4500K / 6200K

閃光 + LED模式

1. 閃光功率：1/8、1/4、1/2、1/1
2. 預設 LED 色溫：6200K
3. LED 亮度不可調

安裝到相機方法

1. 開機
2. 將閃光燈滑入相機熱靴
3. 開機使用

充電方式

1. 5V USB-C 輸入充電
2. 接上合適的充電線和 USB 電源
3. 綠燈亮表示充電完成

技術規格

電池：	3.7V 300mAh (1.11Wh)
閃光功率：	GN8
閃光色溫：	6500K
閃光重置時間：	4 秒 (最大功率)
閃光次數：	約 480 次 (最大功率)
LED 續航時間：	約 1小時 (最大功率)
LED 顯色指數：	> 95
LED 數量：	12顆, 120度
最大亮度：	200Lux / 0.3公尺 / 6200K
LED 色溫：	2500K / 3200K / 4500K / 6200K (±200K)
充電時間：	約 1 小時 (5V 1A)

配件包含

- Mini A 閃光燈本體 • USB-C 充電線 • 手繩

Warranty Card 保修卡

Phottix offers warranty service and / or replacements that comply with local regulations.

Keep this card - DO NOT LOSE.

Phottix 將會按當地法規提供保修 / 更換服務。
請小心保存此卡，不要遺失。

Phottix.com



Printed in China